



FUSELAGE IS CONSTRUCTED AS FOLLOWS:
 BUTT-GLUE THE PLYWOOD & Balsa BOTTOM
 PIECES & THE STAB FLAT ON YOUR BUILDING
 SURFACE. ADD THE FIREWALL & BULKHEADS
 "B" & "C". GLUE THE DOUBLERS & SIDES IN PLACE.
 ATTACH THE FIN & TOP SHEET. LIFT OFF
 THE BOARD AND FINISH.

**ROYAL
COACHMAN**

DESIGNED BY DON DEWEY DRAWN BY B. HALSTED

By H.E.