

1 1/4" Dihedral
Each Tip
(2 1/2" Total)

Front Doubler (Make 2)
3mm Depron

Rear Doubler
(Make 2)
3mm Depron

Fuselage Side (Make 2)

Fuselage Top Sheeting

Fuselage Top Former

Suggested Equipment
Turnigy 2204-14T Outrunner
Turnigy Plush 10A ESC
GWS 8 x 4.3 Prop
5gram Servos
2s 500mAh Lipo

Firewall
1/8" Lite Ply

U/C Mount
(Make 2)
1/8" Lite Ply

Tail Skid
1/8" Lite Ply

Ply UC Mounts
Glued To Inside
Of Fuz Sides

Note: Cabanes and Doublers Glued to Outside of Fuselage Sides

Cabane Struts
(Make 2)
1/8" Lite Ply

Crack Wing At Centre
Line, Bend To Dihedral
Angle and Fill Joint
With Epoxy

Fin

Hinge
With Tape

All Parts FFF or 6mm Depron Unless Otherwise Stated

U/C Make from
1/16" Piano Wire

Cut Hatch
In This Area
For Lipo Access

Optional Headrest

Wing (Make 2)

Glue BBQ Skewer
To LE Of Wing

Tail

1/4" SQ Balsa
Joiner

Optional 3mm Depron
Doubler (Sand to taper)

Wing Dowels From
BBQ Skewers

Bind U/C Wire
To Ply Mount
With Thread
And Glue

Light Foam
Wheels

Servo Tray

Hinge
With Tape

Bottom Sheeting (Front)

Bottom Sheeting (Rear)

Depronker Bipe

Designed by Stephen Minshall

May 2010

Get Sport on RCGroups.com

V1.0

Private Use Only

All Commercial Rights Reserved