Dihedral Brace 1/32 Ply

1/4 Sq. L.E.

1/8 Gussets

1/8 Sq.

1/8 Tip Rib

1/8 x 1/2 Spruce

1/16 Sht.

1 1/2 Dihedral Under Each Tip

1/8 Sq.

DB DB

Windshield

Cut Long Tank

3/32 Balsa

1/8 Ply

3/8 Balsa Cowl

Dowel 5/32

1/8 Sq. Spruce

3/32 Balsa Doubler (3) Pieces

Cut Hole For Exhaust

1/8 Ply

3/32 MW

1/4 Wheels

1/8x1/4

TYP. FORMERS 5 8 6

Cowl

1/8 Ply

3/32 Balsa

W2

Trim 1/16 off Top W2 (7 Reqd)

Fuse Sides 3/32 Balsa

3/32 Balsa (Crossgrain)

Rudder & Fin 1/8 Sht

1/8 Dowel

3/16 Sht

3/32 x 3/16 Typ

3/16 x 1/4

1/8 Sht

3/16 Sht

Span 36" Length 25"

BASIC LOW WING TRAINER

by Randy Wrisley

B.L.T.

MODEL BUILDER magazine

Plan No: 10842