



**STEPS IN WING  
AND STABILIZER  
CONSTRUCTION**

1. PIN LEADING EDGE, SPAR AND TRAILING  
EDGE TO BOARD.

2. GLUE RECTANGULAR 1/16" BALSA RIB  
BLANKS IN PLACE.

3. CUT RIBS TO APPROXIMATE SHAPE WITH  
SCISSORS, FINISH WITH SANDING BLOCK.

