



TYPICAL FUSELAGE CONSTRUCTION

NOTE: 1/16" SHEET FUSELAGE COVERING OMITTED FOR CLARITY

NOTE: NO DIHEDRAL IN TOP SURFACE

3/32" PLYWOOD WING JOINER CEMENT TO BOTTOM SHEET BEFORE ADDING TOP SHEET

1/16" X 1/8" SIDE STRINGER. SAND TO SHAPE AFTER CEMENTING IN PLACE

FORM COWL SIDES & BOTTOM FROM 1/8" SHEET ADD COWL AFTER SHEET COVERING THE FUSELAGE

CUT HOLE FOR PUSH ROD

ALL GUSSETS 1/8" SHEET

DOOR ON THIS SIDE ONLY

3/32" PLYWOOD L.G. MOUNT

BLACK TRIM-FILM

COOLING VENT

SCALE PROP. 6-5/8" D.

CUB .14

HARD 1/8" X 1/4"

STRUTS BUTT AGAINST W-3

5/16" X 3/8" X 2-1/8" HARDWOOD MOUNTS

TOP SHEETING NOT SHOWN ON THIS HALF

3/32" PLYWOOD BELLCRANK MOUNT

3/32" DOWEL SOFT BLOCK

1/16" SHEET COVERING

1/8" SHEET OFFSET 1/2"

BLUE WHITE RED

1/8" SHEET

CONTROL HORN

CLOTH HINGES

1/8" X 1/4" HARDWOOD SPAR

ADD TIPS AFTER COVERING WING