

CENTERLINE

1/8" X 3/16" L.E.

1/20" SHEET (TOP ONLY)

1/16" MED. HARD Balsa STAB

1/8" SQ.

1/16" X 1/4"

3/8" TAPERED T.E.

2-1/4"

1/16" PLY GUSSETS

1/20" OR 1/16" WING RIBS

TIP RIBS

FORMER TOPS MAY BE ANGLED OR ROUNDED

1/16" DIA. WIRE GEAR-BOLT TO PLY FORMER

COCKPIT

2° RIGHT THRUST

1/16" DOUBLERS

SOFT HOLLOWED BLOCK

CELLULOID WINDSHIELD

SOFT BLOCK

1/16" SHEET FORMERS

1/4" SQUARES

1/16" MED. SHEET

C.G.

.010 TO .020 POWER


SOFT BLOCK

FAIRING

1/2" TREXLER AIRWHEELS

1/16" MED. SHEET SIDING

1/16" SHEET BOTTOM



THE "GNAT"

D.J.M.