

MINI BEE

BEFORE STARTING BUILDING

START ASSEMBLING AFTER REFERING
THE DIE CUT BALSA AND PLYWOOD
PARTS TO THE NUMBER ON THE PLANS.

FOR BETTER FINISH AND FLIGHT PERFORMANCE, TAKE TIME
IN READING BUILDING INSTRUCTION AND REFERING TO
THE PLANS, AND ASSEMBLE IN GOOD ORDER AND
CORRECTLY AND CAREFULLY.
CUT OFF EACH PART WITH CUTTER OR RAZOR BLADE
AVOIDING DAMAGE, PARTICULARLY ON THE JOINTING CUT
OUT AND SLOT.
IF NECESSARY TRIM THE PARTS FOR EASIER FITTING. WHEN
CEMENTING USE THREAD, RUBBER BAND, PINS, CLOTHE
CLIPS ETC UNTIL CEMENT SETS FOR FORMING AND WORKING.
CUTTER, BALSA PLANE AND/OR FILE ARE TO BE USED.
WOOD TIP WRAPPED WITH SAND PAPER CAN ALSO BE
USED AS A FILE.

