REAR SECTION OF LEADING EDGE IS CUT AWAY TO RECEIVE WING TIP. (SEE SKETCH BELOW)

PITOT TUBE (SEE DETAIL ELSEWHERE)

ROUND LEADING EDGE OF WING AFTER WING IS ASSEMBLED

STICK STAR TO WING IN THIS POSITION.

RED LIGHT

3/32"X3/16" BALSA CENTER SPAR

1 "C" RIB REQUIRED

RIBS MAY BE LIGHTENED IF DESIRED BY CUTTING AWAY THESE PORTIONS.

RIB A 8 REQUIRED

RIB B 2 REQUIRED

COVER WING WITH TISSUE ON TOP AND BOTTOM

SECTION A-A

DIHEDRAL FORMER

BLACK COLOR STRIPE

GLUE 3/32" SQ. STRUT SEAT FLUSH WITH BOTTOM OF WING RIB.

3/32" X 3/16" BALSA TRAILING EDGE

BLACK COLOR STRIPE

AFTER WING IS ASSEMBLED SAND TIP TO SHAPE SHOWN ABOVE.

CUT WING TIPS FROM THE 3/32" PRINTED BALSA SHEET

STIFF PAPER TRIM TAB

TAPER TRAILING EDGE AFTER ASSEMBLED WING IS REMOVED FROM THE PLAN.

AILERON SEPARATION (NOTE ELSEWHERE ON PLAN)

CONSTRUCT WING DIRECTLY OVER PLAN. PIN CENTER SPAR AND TRAILING EDGE IN PLACE AND GLUE RIBS TO THEM. THEN CEMENT LEADING EDGE TO RIBS. GLUE WING TIPS IN POSITION. WHEN THIS UNIT IS ENTIRELY DRY, REMOVE FROM PLAN AND SANDPAPER LEADING AND TRAILING EDGES AND WINGTIPS. NOW CRACK WING SPARS IN THE CENTER AND CEMENT DIHEDRAL ANGLE IN WING (SEE FRONT VIEW)

GLUE ASSEMBLED NOSEPIECE LIGHTLY TO FORMER 1. THEN PROCEED TO SHAPE IT. THIS INSURES A NOSEPIECE THAT FLOWS IN SMOOTHLY WITH FUSELAGE LINES

BUILD ELEVATOR IN ONE PIECE OVER PLAN WHEN JOINTS ARE DRY, REMOVE FROM PLAN AND COVER ON BOTH SIDES WITH TISSUE.

3/32" SQ. STRIPS

BEVEL ELEVATOR AS SHOWN IN THIS SECTION

BEVEL RUDDER AS SHOWN IN THIS SECTION

BETWEEN THIS WITH POSITION OF ELEVATOR IN SLOT IN FUSELAGE.

SECTION OF LEADING EDGE OF WING.

LEADING EDGE WITH END CUT TO ACCOMMODATE WING TIP.

NOTE: MOST OF THE STRINGERS ARE LEFT OUT OF THE TOP AND SIDE VIEWS OF THE FUSELAGE TO AVOID CONFUSION

PROPELLER IS NOT SHOWN IN TOP VIEW

RUDDER

RUDDER LIGHT

HEADREST

CELLULOID WINDSHIELD

BACKBONE STRIP

NOTE: DIHEDRAL ANGLE IN WING MAKES MODEL STABLE IN FLIGHT

RUDDER

PITOT TUBE

1-1/2" DIHEDRAL

3/32" SQ. BALSA STRUT SEAT GLUED TO INSIDE OF RIB

NOTE: AILERON, RUDDER AND ELEVATOR SEPARATIONS ARE REPRESENTED BY THIN, BLACK PAPER STRIPS STUCK IN PLACE. SEPARATIONS MAY BE DRAWN ON WITH A RULING PEN AND INK.

PIN

MAKE PITOT TUBE OF 1/16" SQ. BALSA SANDED ROUND. ASSEMBLE AS SHOWN ABOVE. STICK INTO LEADING EDGE OF LEFT WING PANEL

RUBBER BAND

THE WING IS HELD ON BY 2 RUBBER BANDS

WINDSHIELD

HEADREST

ELEVATOR

MODEL IS POWERED WITH FOUR STRANDS OF 1/8 FLAT RUBBER.

WING RIB

CENTER SPAR

WHEN GLUING THE DIHEDRAL ANGLE IN WING, CEMENT DIHEDRAL FORMER TO CENTER SPAR AS SHOWN IN SKETCH AT RIGHT. SUPPORT WING IN THIS POSITION UNTIL GLUE IS THOROUGHLY DRY.

DIHEDRAL FORMER

CEMENT COCKPIT COWLING TO FORMERS 6 & 7 BEFORE COVERING THE FUSELAGE

CUT CELLULOID WINDSHIELD TO THIS SHAPE AND GLUE TO COCKPIT COWLING.

COLOR SCHEME

WINGS & TAIL ARE YELLOW WITH BLACK TRIMMINGS

FUSELAGE IS BLACK WITH YELLOW STRIPE

LANDING GEAR STRUT

FRONT VIEW 1/2 SIZE

BEVEL INSIDE CORNERS OF WING REST STRIPS

RUDDER LIGHT

CUT FROM THE 3/32" PRINTED SHEET

TAPER THE TRAILING EDGE AS IN THIS SECTION

3/32" SQ. STRIPS

PIN

RUBBER MOTOR

CEMENT MOTOR MOUNT PIECES BETWEEN STRINGERS AND PUSH PIN THRU TO SUPPORT RUBBER MOTOR AT REAR OF FUSELAGE

1-1/2" WHEEL

APPLY CEMENT GENEROUSLY AROUND PIN THAT SERVES AS AN AXLE.

BEND PIN TO SHAPE SHOWN BELOW AFTER WHEEL IS SLIPPED ON.

WING POSITION CAN BE ADJUSTED ON WING REST STRIPS

PUSH PINS THRU WING REST STRIP ALLOWING HEAD TO PROTRUDE 3/32". BEND PIN AS SHOWN AND CEMENT WELL.

SANDPAPER STRUTS TO A STREAMLINED SECTION

ELEVATOR SEPARATION

SAND LEADING EDGE ROUND

CEMENT THE TWO SIDES OF DUMMY PILOT TO BALSA PIECE. THEN GLUE HEAD OF PILOT TO HEADREST

CUT TWO HEADREST PIECES FROM 3/16 BALSA AND CEMENT TOGETHER. THEN SHAPE AS IN TOP AND FRONT VIEW

CUT THESE SMALL FAIRINGS FROM BALSA SHEET AND CEMENT TO FORMERS 4&5 AT BASE OF STRUT

CABANE STRUTS

RUBBER BAND

BUILD CABANE STRUTS OF 3/32" X 3/16" BALSA OVER THIS PATTERN

LOWER PORTION OF STRUT IS GLUED INTO NOTCH IN FORMER

FRONT VIEW OF CABANE STRUTS

BLACK COLOR STRIPE

SANDPAPER EDGES OF ELEVATOR ROUND

CUT ELEVATOR TIPS FROM 3/32" BALSA PRINTED SHEET

BLACK COLOR STRIPE

RUDDER SEPARATION

ELEVATOR SLOT

COCKPIT COWL

BROKEN LINES SHOW POSITION OF YELLOW COLOR STRIPE

1/16" SQ. BALSA STRINGERS

SHORT 3/32" SQ. BALSA STRINGER

BACKBONE STRIP

PROPELLER SPINNER

BEND SHAFT OVER AND GLUE TO PROPELLER BEFORE CEMENTING THE SPINNER IN PLACE.

PROPELLER SHAFT

WASHER, BEAD, WASHER

MACHINE-CARVED PROPELLER

GLUE INSTRUMENT PANEL TO FORMER 6

NOTE AFTER MODEL IS ASSEMBLED, SPRAY TISSUE COVERING WITH WATER TO MAKE IT TAUT

RUDDER TAB

CEMENT TAILSKID FIRMLY INTO SLOT IN BACKBONE STRIP

A PORTION OF FUSELAGE MAY BE LEFT UNCOVERED FOR ACCESS TO MOTOR

FUSELAGE CONSTRUCTION

PIN BACKBONE STRIPS IN THEIR PROPER POSITION OVER SIDE VIEW OF PLAN AND CEMENT RIGHT HALVES OF FORMERS IN PLACE PERPENDICULAR TO PLAN. WHEN JOINTS ARE DRY, REMOVE FROM PLAN AND CEMENT THE OTHER FORMER HALVES ON. THEN ATTACH STRINGERS IN PAIRS, ONE ON EACH SIDE, TO PREVENT DISTORTION OF FUSELAGE.

JOINT IN BACKBONE STRIP

THIS SHORT STRINGER EXTENDS BETWEEN FORMERS 2 AND 4.

WASHER, BEAD, WASHER

PROPELLER INSIGNIA

NOSEPIECE

PROPELLER SHAFT

SPINNER

MOUNT NOSEPIECE, WASHERS, BEAD AND PROPELLER ON SHAFT. THEN BEND OVER AS SHOWN, PULL BACK IN PROPELLER AND CEMENT.

GLUE HALVES OF FORMER 9 TO BACKBONE AFTER IT IS REMOVED FROM BOARD

THE 1/16" SQ. STRINGERS DO NOT RUN ENTIRE LENGTH OF FUSELAGE. MAKE BUTT JOINT OF EACH 1/16" SQ. STRINGER AT A DIFFERENT FORMER TO INSURE A STRONG FUSELAGE.

WING STRUT

WING STRUTS FIT IN THESE NOTCHES

CUT LANDING STRUT FROM 3/32" BALSA AND SANDPAPER AS SHOWN IN THIS SECTION

CEMENT A PIECE OF BAMBOO TO LANDING STRUT BEFORE SANDPAPERING TO A STREAMLINED SHAPE.

NOTCH FOR 3/32" SQ. STRIP

1-1/2" WHEEL

TO ASSURE A FREE-RUNNING WHEEL FORCE 1/16" DIA. ALUMINUM TUBING INTO THE HUB.

ABOVE FORMERS ARE CUT FROM THE PRINTED BALSA SHEET.

NOTE: TO ASSURE FULL UNDERSTANDING OF PLAN, READ INSTRUCTIONS CAREFULLY BEFORE BEGINNING CONSTRUCTION OF MODEL.

LANDING GEAR STRUT FITS IN THIS NOTCH

THIS FORMER IS CUT FROM 3/32" BALSA TO INSURE A STRONG LANDING GEAR UNIT.

FLYING INSTRUCTIONS

GLIDE FINISHED MODEL TO OBTAIN THE CORRECT WING SETTING. MOVE WING FORWARD IF MODEL DIVES. IF MODEL STALLS, MOVE WING BACK. FURTHER ADJUSTMENTS CAN BE MADE BY ADDING WEIGHT (SMALL TACKS) TO BACK OF NOSEPIECE.

THE TORQUE OF THE SPINNING PROPELLER TENDS TO BANK THE MODEL IN A LEFT CIRCLE. IF MODEL BANKS TOO STEEPLY IN THIS CIRCLE, BEND WING TRIM TAB DOWN. SETTING THE RUDDER TAB TO THE RIGHT ALSO HELPS TO COUNTERACT THIS. MODEL SHOULD FLY IN A LARGE, LEFT CIRCLE.

WHEN SHORT FLIGHTS SHOW MODEL TO BE CORRECTLY ADJUSTED, WIND RUBBER MOTOR TO CAPACITY. WHEN MODEL IS MADE TO TAKE OFF FROM THE GROUND, MAKE CERTAIN THE WHEELS ROLL FREELY.

COMPUTERIZED 7/22/99
ROLAND FRIESTAD
FULL SIZE PLANS ARCHIVE NUMBER F002188
www.fullsizeplans.com

SENIOR DIPPER

WINGSPAN - 24" | LENGTH - 19"

KIT NO. SA-194 | SERIES - FLYING

DRAWN BY [illegible] | LETTERED BY [illegible]

21.7 X 25.5

1937 [illegible]