





ENLARGE SQUARES TO 1/4" FOR FULL SIZE RIBS.

WING PLAN 1/4 SCALE

5/16" x 1 1/2" TRAILING EDGE

1/4" SHEET

1" SHEET

#1 SPAR 1/4 x 3/4"

#2 SPAR 1/8 x 1/4"

1/4" SQ.

3"

TIE PLATES

1/6" SHEET ON TOP ONLY

2 3/4"

THIS SECTION COVERED WITH 1/6" SHEET ON BOTTOM ONLY

TIE PLATES

PERSPECTIVE NOT TO SCALE

METHOD OF STRENGTHENING SPAR JOINT AT CENTER SECTION BY USE OF PLYWOOD TIE PLATES 1/6" THICK.



