BUCKER JUNGMANN
designed by
ERIC COATES

£1

copyright of
The Aeromodeller Plans Service
13-35 Bridge Street, Hemel Hempstead, Herts.

Interplane struts shown chain dotted. 1/8 Dowel plus 1/8 sq. hard balsa shaped to aerofoil section.

Fibreglass

Light Alloy Cowl

1/8 balsa sheet top section

Top Stringers 3/32 sq. Spruce

2 X 3/32 sq.

2X1/16sq.

2X1/8sq.

1/8sq.

1/32 Balsa sht core

1/8sht.

1/8X1/8 ribs

Alloy Trim Tab

Datum

Mills 13cc shown

Plans 1/8X1/4 to here

3/16 Soft sht. on top of 1/8sht.

Longerons 1/8sq Spruce

1/8sq Balsa cross bracing

3/16X1/16 Spruce

2X1/8sq.

1/8 sht.

1/8 sht.

1/16 Doubler

Lower Stringer 1/16X 3/16

Metal Foil overlay

1/16 sht. ribs

20swg Frame

Mudguard 20swg. Alum. sht. Araldite to 20swg. wire stays.

18swg Brass Tube

22swg

18swg

Front Cabane

18swg Brass Tube

22swg

18swg

Rear Cabane

18swg Brass Tube

18swg

Intermediate Cabane

All Cabane wires shown are true length

Landing wires continuous 'V' 22swg

16swg. wire joiner bind with fuse wire and solder at crossings

Flying wires continuous 'V' 22swg.

Rubber bands

20swg hooks Araldite to spar

16swg.

16swg

12swg bound with paper

Bind and Araldite apex of 'V' bracing to appropriate former

Tailplane Bracing 24 swg.

Top decking omited for clarity aft of Former 2.

Bearers 1/2 X 3/8 Ramin

Fillet 1/16 Sheet.

C.S., L.E. 1/2 X 0·3 Hard Balsa

1/8sq Balsa spars

2X1/16 sq.

2X1/8 sq.

1/8 sq

2 X 3/32 sq

1/32 Balsa sht core.

Alloy Trim Tabs

12swg tube with slot cut in

Tinplate Tags Araldited to spars, solder bracing wires as shown.

Ribs 4 Off 1/16 sht. 4 off 1/8 sht.

Detail of Hook 20swg. 6off

F2a. 1/16 Balsa

F3a 3/32 Balsa

F6

F7

F8

F9

Formers F5 - F9 3/32 Balsa

F2 1/8 Balsa

F3 1/8 Balsa

F5a

F5

F10

F4 1/8 Balsa

1/2 X0·3 L.E.

1mm Ply

Hook - top of bottom wing

14swg Tubes

3/8sq blocks

1/8sq spar

3/32 sq at bottom

1/4 X1/8

1/8 rib

1/4 X1/8

PORT LOWER WING

1/2 X 1/8 Balsa T.E.

1/2X0·3 L.E.

14swg Tubes

Hook - top of bottom wings.

3/8sq blocks

1/8sq spar

3/32 sq at bottom

1/8 Rib

1/4 X1/8

1/4 X1/8

ST'BD LOWER WING

1/2 X 1/8 Balsa T.E.

3/32 Balsa sht.

Hand hold

1/2X0·3 L.E.

1mm Ply

Hooks - underside top wing

1/8sq spar

PORT UPPER WING

1/2X0·3 L.E.

Hooks - underside top wing

1/8dia strut location holes.

1/8sq spar

ST'BD UPPER WING

3/32 sht.

2X32 sq.

3/16 sq