Gun port p. & s.
Engine bearers 3/8" sq.
Control plate mount 1/2" x 3/8" hard
Soft balsa
1/16 ply
Slide inside main tube
Bush plug-in
2a 2b
1/32" ply
2b 2a
Cut slot in tube underside and solder wire in place
Gun/bombsight
soft block
1/32" ply strip
1/32" ply
Mast 1/32" ply bind to wire with silk
3b 3a 3c
1/32" balsa
1/32" ply
1/32" ply
Former 3
Bind fork of mast with cotton & cement to 3a add former 3b complete sandwich with 3c
22g
4 5
1/16" ply
24g
End of push pull rod
2 laminations of 1/8" sht.
Cowling attached by two brackets fixed to engine mounting with 8 b.a bolts and nuts
22g
1 2 3 4 5
paint on
paint on
paint on
paint on
Instrument panel
1/8" hard
A B C D E F G H J K
1/8" sq hard
1/8" hard
outline of fin
Soft block
Fuel tank
16g
16g
Soft block
1/2" x 1/8" hard
Hollow from block
Gummed paper
Bomb release
Cover fuselage with 1/8" sht.
Formers C & E
Cut 2 each 1/16" ply
1 each 1/8 hard balsa
1/8" hard balsa
B F
H G
1/8" balsa
3/16 balsa
D
C G
Bomb steady
1/16 ply
K J
1/8" balsa
C E
C1 E1
A
Cut 1 from 1/16" ply
1 from 1/8" balsa
Position of bomb crutch pivot tube
Tail wheel strut
Bind with thread cement to keel and underside of tailplane
U C 12g bind to former C with linen thread
2 Laminations 1/8 sht.
Elevator horn detail
Bind & solder
18g horn sandwich between loms.
Linen hinges sandwiched between laminations
Silk patch
Cut 4 from 1/8" sht.
X
Cut 4 from 3/16 sht.
Y
Z
Cut 4 from 1/8" sht.
X Y Z
Wheel spat 1/2 section
Formers BCD
B.C. 1/8" balsa
D 1/16" balsa
1/16" ply lamin.
F2 3/16 balsa
A 1/16" balsa
1/16 ply lamin.
F1 1/8" balsa
Jig outline
1 2 A B C D
1/16 ply each side
Cement former 2 to A slide on to jig with B (tack in position with 1/8 sq. strip) wrap 1/16 sht. around formers. When dry wrap around a second layer. Add former 1 sand and dope Trim off to B slide C and D on jig Wrap with 1/16 sht trim off and dope Cover cowl with silk and dope Add 1/32" ply gills
Jig cut 2 from 1/8" sht. cement to form cross
L.E 1/2 sht
1/8 sht on underside
M Spar 3/16" sht very hard
1/2-2 oz lip weight
Navigation lamp
Laminated sht top
R1 R2 R3 R4 R5 R6 R7 R8 R9 R10
1/8" sht
1/8" sht
Notch T.E of wing and cement in place
1/15" ply keys
1/8" sht ribs
1/8" sht ribs
1/16" sht
Typical flap/aileron cross section
Aileron spar 1/8 sht
1/16" sht top and bottom
Silk patch
Flap spars 1/8" sht.
Silk patch
Line guide
Leadout wires of l/w laystate inboard
Paper Tubes
M Spar
Dive brakes
Notch underside of wing and cement in place
Divebrakes 1/16" ply
R1 1/8 hard balsa sht
R2
R3 R4
Cutaways in inboard wing ribs only
R5
R6
R7
R8
R9
R10
All ribs 1/8" sht.
Up elevator
Keel
Trigger 16 g
16g bush cement keel
18g lever attach to control plate
20g bush cement to keel
20g safety rod
Spring tension
16g torque tube
18g
3rd line
18g main operating lever
18g bracket mount to c.s. spar
Tension spring
16g control crank
18g operating rod
Brass bush bind with thread and cement well
16g
Keel
Spring
1/4 balsa port side only
Hard balsa
1/8 disc
Soft balsa
2 laminations 1/32" balsa
Cut 1 from 1/16" sht
Cut 1 from 1/8 sht. 1 from 1/16"
Slot for bomb release trigger must be on stbd. side
Fit ends of tube with solder to retain on pivot pin
Solder blobs here
20g wire bend ends and insert in tube
Flatten end of tube and file to hook
Brass tube
18g wire
16g aluminium tube
Dive brake brackets 6 off 1/32" ply
Bind with thread cement to wing as shown
Line guide 18g
3rd line if used

AICHI 99 VAL
ma 349 C.P.G. Wheldon 5/6
LENGTH 28" SPAN 39"
ENGINE 2.5-5cc
© Model Aircraft 1961
19-20 Noel St London W1